




# "ATOMIC PUNK"

OWNERS MANUAL — ATOMIC PUNK®



# VIDEO GAME OPERATOR:

Don't Get Involved In A Federal Crime. Don't  
Buy Or Operate Copy Or Unauthorized Boards In  
Your Games.

## Warning



*Every operator who buys or  
operates a counterfeit or unauthorized  
board (imported or domestic) is  
contributing to the end of our industry  
and committing a FEDERAL CRIME.*

*New criminal laws have recently  
been enacted that provide for maximum  
penalties of \$250,000 or five years in  
prison or both, per offense. EACH  
GAME IS A SEPARATE OFFENSE.*



### WARNING

Federal law provides severe civil and  
criminal penalties for the unauthorized  
reproduction, distribution, or exhibition of  
copyrighted audiovisual works and video  
games.

The Federal Bureau of Investigation  
investigates allegations of criminal  
copyright infringement.

*If you have any information about any  
unauthorized games in the United States,  
contact your local FBI or,*

*American Amusement Machine Association*

205 The Strand  
Suite 3  
Alexandria, Virginia 22314  
(703) 548-8044

All information will be treated in confidence.

## **SAFETY**

The following topics should be carefully studied to insure maximum reliability and safety for both serviceman and customer. Shock Hazard: The high voltage present on the monitor may be very dangerous. Extreme caution must be used when working with or around the monitors. Be certain that the grounding strap is attached to the monitor frame. The picture tube in the monitor is also a hazard and should be handled with care. Do not strike, scratch, or subject the tube to more than moderate pressure as it may implode causing serious injury from flying glass. Be certain that the control panel, power supply monitor, and coin door are all properly grounded to the ground wire inside the line cord. Do not remove ground prong off plug end.

## **PARTS LIST**

- 1 - Bezel
- 1 - Plex Marquee
- 2 - Control Panel Overlays
- 1 - FCC Cage and Label
- 8 - I.D. Tags
- 1 - Manual
- 12 - Buttons
- 1 - JAMMA Cable
- 1 - 3rd & 4th Player Cables
- 1 - Marquee Art
- 1 - PCB
- 4 - 4 Way Joysticks & Hardware

### **IREM AMERICA CORPORATION®**

8333 154th Avenue NE  
Redmond, WA 98052  
(206) 882-1093

### **FOR SERVICE CONTACT:**

Your authorized Irem America Corporation® Distributor  
or

#### **SUMMIT SERVICE**

2274 University Avenue  
St. Paul, MN 55114  
(612) 645-9077

## **WARRANTY REPAIRS**

Irem America Corporation PCB have a 90 day warranty from date of shipment. This includes all failures except those caused by the installer such as miswiring.

All PCB must be returned by an authorized Irem America Corporation distributor. A Return Material Authorization must be obtained from Summit Service prior to returning material. A Purchase Order must also be given to Summit Service at this time. The package must be clearly marked with the RMA number.

**ATOMIC PUNK®** is protected by federal copyright laws and is the property of Irem America Corporation®. Any unauthorized versions of this game are illegal by federal law. AAMA protected stickers must be attached to the PCB. Please notify Irem America Corporation of any boards not having the AAMA seal.

## IMPORTANT F.C.C. WARNING

THIS EQUIPMENT COMPLIES WITH THE REQUIREMENTS IN PART 15 OF FCC RULES FOR A CLASS A COMPUTING DEVICE. OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA MAY CAUSE UNACCEPTABLE INTERFERENCE OF RADIO AND TV RECEPTION REQUIRING THE OPERATOR TO TAKE WHATEVER STEPS ARE NECESSARY TO CORRECT THE INTERFERENCE. YOUR FCC COMPLIANCE LABEL IS ENCLOSED IN YOUR KIT AND MUST BE ATTACHED TO YOUR GAME PRIOR TO PLACING ON LOCATION. THIS LABEL INDICATES YOUR GAME WAS DESIGNED TO MEET FCC STANDARDS 47CFR15.19. WE ADVISE USING STAPLES IF NECESSARY TO MAKE SURE THE LABEL STAYS ON.

## DANGER

The isolation transformer must be used with the monitor and power supply.

This game must be equipped with a three wire 110 volt plug for safety. Under no circumstance remove the ground plug.

## DANGER

This game is designed with a JAMMA 56 pin connector. This plug is one of the finest operator friendly features in our industry today. What this means to you is that:

- 1) 1, 2, A, B, 27, 28, e and f are grounded
- 2) 3, 4, C and D are +5 volts
- 3) 5 and E are -5 volts
- 4) 6 and F are +12 volts

Also, all video and joystick functions are always in the same place. Once a cabinet is wired for JAMMA, it is easily changed from game to game.

Many older games such as Pac Man®, etc., have the power supply on the board. This will not work!!! Only a JAMMA connector with proper voltage will work. Irem America Corporation® recommends using an 11 or 15 amp switching power supply with **Atomic Punk®**.

## MONITORS

**Atomic Punk®** is designed to be operated with a horizontal raster scan monitor with negative sync (RGB). This means **Atomic Punk®** will not work with any X-Y (Tempest, Space Dual, Star Trek), etc. An isolation transformer must be used in conjunction with the monitor. This is for your safety. The monitor also utilizes extremely high voltages. The monitor may also retain a charge for an extended period of time. Safety goggles must be worn while removing or replacing the monitor.

It is highly recommended that the monitor is verified good before the new **Atomic Punk®** kit is installed in your new and or rebuilt cabinet.

# INSTALLATION OF KIT IN USED CABINET

## To Disassemble:

1. Open back door and remove old board set and power supply, if you are using a new switching power supply.
2. Remove marquee glass and monitor glass.
3. Remove control panel and set aside.
4. Remove old wire harness, leaving 110 volt wiring intact. Also, leave the grounding straps to the monitor, coin door, control panel, and power supply intact.

## Installation:

1. Mount the board set on the side panel of the cabinet as close to the middle of the game as possible (approximately 10-12" off bottom).

**NOTE: Do not mount board directly below control or any vents or cracks so that liquids may seep on to the board. Do not forget about coins that may drop on to the board. Also, mount the board with edge connector facing up.**

2. Mount the power supply on the bottom of the cabinet with connectors facing the rear of the cabinet. An optional mounting might be on the side panel just below the board set, connector to rear.
3. If the game does not have an isolation transformer, you must protect your customers and your game. Install one between the 110 volt line and your monitor/power supply.
4. Place the provided JAMMA wiring harness on the board. Connect the +5, +12, -5, and ground wires to the corresponding lugs on the power supply, connecting all the wires. If you don't, you will probably burn the board connector.
5. Run a wire from +12 volts to the coin door lights. Run a wire from +12 volts to the coin counters. This completes the power requirements.
6. Connect the Audio (+) and Audio (-) to the speaker.
7. Connect the video red, green, blue, ground, and sync to the corresponding wires on the monitor. If the monitor is not a negative composite sync, see sync modifications chart.
8. Cut the marquee to size. Replace the marquee lamp, if needed. Install the marquee panel.
9. Connect the coin 1 and coin 2 wires to the coin switches. Connect the coin counter 1 and coin counter 2 wires to the coin counters.

**NOTE: If you only have one coin counter, see coin counter diagram. It will not matter if the coin counters are only rated at 6 volts, as the pulse is not long enough to burn out the counter.**

10. Disassemble the control panel of all the hardware. Do not remove the old panel overlay. Determine where to place the new joystick and buttons if they must be repositioned. Then, cut new holes.

**NOTE: If you are going to use plexiglass over the control panel, we suggest that you use a good 1/8" polycarbonate with a scratch resistant coating. We recommend GENERAL ELECTRIC LEXAN MR5 with margard or TUFFAK CM-2. These do not crack or break with abuse.**

Cut and drill plex as needed. Remove the old control panel overlay carefully and apply the new overlay on top of the old glue. Use an **Exacto** knife to cut out any button or bolt holes. Apply necessary decals over appropriate buttons. Now assemble the control panel.






11. Bolt the control panel to the cabinet. Now connect the appropriate wires to the correct switches. Connect the 1 player and 2 player start wires.
12. Be sure to install the FCC cage to avoid unnecessary radio frequency interference.
13. Power up the game. Look over your installation for errors, and then apply power, listening for unusual sounds. Check for smoke or sparks. If everything is okay, wire tie all wires to form a nice, neat wiring harness. Clean the cabinet inside and out. Measure the +5 volts on the furthest point from the edge connector and adjust 5 volts to 5.05 volts. Use a tinted plex over the monitor if there are burns in the screen. We suggest bronze or grey tinted plex. Touch up the cabinet with fresh paint, and then repair all cabinet dents or chips, using an auto body product called **Duraglass**. This is similar to bondo. You can consult your local auto body shop or auto parts supplier for this product, as well as advice on how to use it.
14. Be sure your ground plug is good. All metal exposed to the player must be grounded (coin door, control panel, etc.) including all metal inside exposed.

## ATOMIC PUNK®


Irem America Corporation recommends installing your new **ATOMIC PUNK** kit in only a new or refurbished cabinet. Installing **ATOMIC PUNK** in an older cabinet will result in lower earnings. The cabinet should be as follows:

1. horizontal monitor
2. 11 amp or larger power supply
3. monitor not laying down flat.

START




## SUPER JOYSTICK



**Featuring:**

- Nylon and solid steel construction
- Micro or leaf switches individually replaceable
- Unique handle design
- Spring return to center
- Rugged actuator for long life
- Change actuation to 4-way or 8-way simply by flipping actuator over



**PARTS LIST:**

- |            |                              |            |                              |
|------------|------------------------------|------------|------------------------------|
| 96-1400-00 | Chrome shaft & knob          | 96-1401-00 | Hub for microswitch joystick |
| 96-1015-00 | Washer                       | 96-1409-00 | Leafswitch                   |
| 96-1302-00 | Pivot cone                   | 95-0737-00 | Microswitch                  |
| 96-1403-00 | Blade holder                 | 96-1402-00 | 4-way 8-way actuator         |
| 96-1405-00 | Hub for leaf switch joystick |            |                              |

# HAPP CONTROLS, inc.

106 Carlisch

Elk Grove, Illinois 60007

Phone: (312) 593-6130

Telex: 297249 CONTROLS UR

**PARTS LIST:**

96-1400-00	Chrome shaft & knob	96-1401-00	Hub for microswitch joystick
96-1015-00	Washer	96-1409-00	Leafswitch
96-1302-00	Pivot cone	95-0737-00	Microswitch
96-1403-00	Blade holder	96-1402-00	4-way 8-way actuator
96-1405-00	Hub for leaf switch joystick		

## 25 +

13 95

13.95

•

## 1. Monitor Sync

If your monitor does not have dual polarity positions for sync, you may use one of the following methods to get your game going.

**CURE 1:** Install a simple one I.C. circuit on your logic board. This I.C. may be "piggy backed" on to another 7404 series chip for power by bending up all but the two power pins so that they are parallel to the top surface of the new I.C. and then connecting the power pins only to the existing chip. (See Fig. 1) Next connect the sync wires as shown in Fig. 2. (Note: Figure 2 shows a hookup for either **composite** or **separate syncs**.)




FIG. 1





FIG. 2



**CURE 2:** Used for Wells-Gardner Video-Sync boards with positive sync connections only. (Vertical mount board 85x14 OB.)

Cut the traces on the solder side of the board between input pins 5 & 6 to the unbanded (anode) ends of diodes X201 & X202.

Add MPSA 56 transistor as follows:

Collector to anode leads of diodes X201 & X202. Base pins 5 & 6 of the video input connector. Emitter to cathode (banded) lead of zener diode ZD201.

Insert a 1N4148 diode - cathode to the emitter of the MPSA56 and anode to the base. (See Fig. 3)




FIG. 3



## 2. Horizontal Tearing

CAUSE: The negative sync signal of most logic sets are slightly different than the GO7-CBO monitor negative sync inputs. The result of this mismatch is a horizontal "wave" or "curl".

CURE 1: On the monitor deflection board, replace C303 with a 10uf 25V radial lead capacitor with the positive lead towards the collector of X305. (CAUTION: be sure to check this step as the original cap is not polarized.) Then replace C501 with the cap removed from the C303 location.

CURE 2: Connect 1N4148 fast-switching diodes across both the positive and negative sync inputs to the monitor. (See Fig. 4) NOTE: Both diodes must be installed or you will not have vertical stability.





FIG. 4




CURE 3: Join negative sync inputs J2 and J3 together with a jumper. Locate W102 and install a jumper from W102 to either J2 or J3.

CURE 4: For Wells-Gardner K4600 series monitors.

Replace C356 (4 7uf 25V) on the Horizontal / vertical board (vertically mounted board nearest the flyback transformer) and center the horizontal hold pot. Turn L351 for the best horizontal stability and fine-tune with the horizontal width pot.

## COIN COUNTER DIAGRAM

If only one coin counter is to be used install two diodes in the following manner:



# ATOMIC PUNK® — HORIZONTAL SCREEN — 4 x 4 WAY JOYSTICK 2 BUTTONS

## DIP-1

FUNCTION		SWITCH	1	2	3	4	5	6	7	8
NUMBER OF PLAYER	3		OFF	OFF						
	2		ON	OFF						
	4		OFF	ON						
	5		ON	ON						
DIFFICULTY	NORMAL*				OFF	OFF				
	EASY*				ON	OFF				
	HARD				OFF	ON				
	VERY HARD				ON	ON				
CONTINUATION MODE	YES							OFF		
	NO							ON		
SOUND IN DEMO	NO								OFF	
	YES								ON	
DIAGNOSTIC TEST	NO									OFF
	YES									ON

## DIP-2

FUNCTION		SWITCH	1	2	3	4	5	6	7	8
FILP PICTURE	NO		OFF							
	YES		ON							
CABINET TYPE	4P UPRIGHT A			OFF	OFF					
	4P UPRIGHT B			OFF	ON					
	2P UPRIGHT			ON	OFF					
	2P TABLE TYPE			ON	ON					
MODE 1	1 COIN 1 PLAY					OFF	OFF	OFF	OFF	OFF
	2 COINS 1 PLAY					OFF	ON	OFF	OFF	OFF
	3 COINS 1 PLAY					OFF	OFF	ON	OFF	OFF
	4 COINS 1 PLAY					OFF	ON	ON	OFF	OFF
	5 COINS 1 PLAY					OFF	OFF	OFF	ON	OFF
	6 COINS 1 PLAY					OFF	ON	OFF	ON	OFF
	1 COIN 2 PLAYS					OFF	OFF	ON	ON	OFF
	1 COIN 3 PLAYS					OFF	ON	ON	ON	OFF
	1 COIN 4 PLAYS					OFF	OFF	OFF	OFF	ON
	1 COIN 5 PLAYS					OFF	ON	OFF	OFF	ON
	1 COIN 6 PLAYS					OFF	OFF	ON	OFF	ON
	2 COINS 3 PLAYS					OFF	ON	ON	OFF	ON
	3 COINS 2 PLAYS					OFF	OFF	OFF	ON	ON
	4 COINS 3 PLAYS					OFF	ON	OFF	ON	ON
	*CONTINUATION COIN					OFF	OFF	ON	ON	ON
	FREE PLAY					OFF	ON	ON	ON	ON
MODE 2	COIN MECH. (A)	1 COIN 1 PLAY				ON	OFF	OFF		
		2 COINS 1 PLAY				ON	ON	OFF		
		3 COINS 1 PLAY				ON	OFF	ON		
		5 COINS 1 PLAY				ON	ON	ON		
	COIN MECH. (B)	1 COIN 2 PLAY				ON			OFF	OFF
		1 COIN 3 PLAYS				ON			ON	OFF
		1 COIN 5 PLAYS				ON			OFF	ON
		1 COIN 6 PLAYS				ON			ON	ON

N.B.

- \* Please operate Dip Switches with Power Switch OFF; otherwise they don't work.
- \* Select Coin Mode 1 in case a single coin selector or two selectors for coins of the same value are used.
- \* Select Coin Mode 2 in case two coin selectors of coins of different values are used.
- \* DIFFICULTY SETTING — Normal Difficulty setting is recommended for 2 player and Easy difficulty setting is recommended for 4 player operation.
- \* CONTINUATION COIN makes the game start with 2 coins, and makes the game continue with 1 coin. This mode does not allow any other coin modes to be set.

# KD/DYNAMO — UNIVERSAL VIDEO WIRING

56 PIN EDGE CONN. PIN-OUT CHART

(JAMMA COMPATIBLE)

COMPONENT SIDE				SOLDER SIDE		
FUNCTION	COLOR	POS	POS	COLOR	FUNCTION	
GROUND	BLK	1	A	BLK	GROUND	
GROUND	BLK	2	B	BLK	GROUND	
+5 VOLTS	RED	3	C	RED	+5 VOLTS	
+5 VOLTS	RED	4	D	RED	+5 VOLTS	
-5 VOLTS	WHITE	5	E	WHITE	-5 VOLTS	
+12 VOLTS	YELLOW	6	F	YELLOW	+12 VOLTS	
KEY		7	H		KEY	
COIN COUNTER #1	BRN	8	J		COIN COUNTER #2	
COIN LOCK OUT 1	RED	9	K		COIN LOCK OUT 2	
SP (+)	WHT	10	L	WHT/BLK	SP (-)	
N.C.	BLUE-OPTION	11	M	OP.-BLU/BLACK	N.C.	
VIDEO RED	RED	12	N	GRN	VIDEO GRN	
VIDEO BLU	BLU	13	P	GRAY	VIDEO SYNC*	
VIDEO GND	BLK	14	R	RED/BLACK	SERVICE SWITCH	
TEST SW.	BROWN	15	S	OP.-BRN/BLACK	TILT SW.	
COIN SW. 1	WHITE	16	T		COIN SW. 2	
START 1	GRAY	17	U	WHITE/GRAY	START 2	
1 P UP	VIOLET	18	V	WHITE/VIOLET	2 P UP	
1 P DOWN	BLUE	19	W	WHITE/BLUE	2 P DOWN	
1 P LEFT	GREEN	20	X	WHITE/GREEN	2 P LEFT	
1 P RIGHT	YELLOW	21	Y	WHT/YELLOW	2 P RIGHT	
1 P PUSH 1	ORANGE	22	Z	WHT/ORANGE	2 P PUSH 1	
1 P PUSH 2	RED	23	a	WHT/RED	2 P PUSH 2	
1 P PUSH 3	BROWN	24	b	WHT/BROWN	2 P PUSH 3	
N.C.	BLUE/WHT	25	c	GREEN/WHT	N.C.	
N.C.	RED/WHT	26	d	YELLOW/WHT	N.C.	
GROUND	BLK	27	e	BLK	GROUND	
GROUND	BLK-OPTION	28	f	BLK-OPTION	GROUND	

\* Video sync composite negative

# ATOMIC PUNK®

JAMMA EDGE CONNECTOR/CABLE

COMPONENT SIDE			SOLDER SIDE		
FUNCTION	COLOR	POS	POS	COLOR	FUNCTION
GROUND	BLK	1	A	BLK	GROUND
GROUND	BLK	2	B	BLK	GROUND
+5 VOLTS	RED	3	C	RED	+5 VOLTS
+5 VOLTS	RED	4	D	RED	+5 VOLTS
-5 VOLTS	BRN	5	E	BRN	-5 VOLTS
+12 VOLTS	BLU	6	F	BLU	+12 VOLTS
PREVENT KEY		7	H		PREVENT KEY
COIN COUNTER #1	BLU/BRN	8	J	WHT/PUR	COIN COUNTER #2
GROUND	BLACK	9	K	BLACK	GROUND
AUDIO POS +	WHT/BLK	10	L	BLK	AUDIO NEG -
		11	M		
VIDEO RED	RED	12	N	GRN	VIDEO GRN
VIDEO BLU	BLU	13	P	WHT	VIDEO SYNC*
VIDEO GND	BLK	14	R	BRN/WHT	SERVICE SWITCH
TEST	YEL	15	S	WHT/BRN	
COIN INPUT 1	WHT/YEL	16	T	GRN/YEL	COIN INPUT 2
START +	<del>WHT/BLK</del> PWR/BLK	17	U	<del>RED/BLK</del> GRN/BLK	<del>WHT/BLK</del> WHT/BLK
1 P DOWN UP	<del>RED/BLK</del> GRN/BLK	18	V	<del>GRN/WHT</del> GRN/BLU	2 P UP
1 P DOWN	<del>RED/WHT</del> GRN/ORG	19	W	<del>GRN/WHT</del> GRN/ORG	2 P DOWN
1 P LEFT	<del>RED/GRN</del> GRN/BLU	20	X	<del>GRN/GRN</del> GRN/GRN	2 P LEFT
1 P RIGHT	<del>RED/RED</del> GRN/RED	21	Y	<del>WHT/GRN</del> GRN/GRN	2 P RIGHT
1 P BOMB	<del>RED/RED</del> GRN/RED	22	Z	<del>BLK/BLK</del> GRN/BLK	2 P BOMB
1 P REMOTE	<del>WHT/RED</del> GRN/GRN	23	a	<del>YEL/WHT</del> BLK/WHT	2 P REMOTE
CONTROL BOMB	<del>YEL/BLK</del> GRN/GRN	24	b	<del>BRN/GRN</del> GRN/GRN	CONTROL BOMB
		25	c		
		26	d		
GROUND	BLK	27	e	BLK	GROUND
GROUND	BLK	28	f	BLK	GROUND

\* Video sync composite negative.

\* Use 4-way joysticks.

\* 2P UPRIGHT WITH  
NO START SWITCHES


- 4-way joysticks, each with two buttons, and a horizontally positioned monitor are required.
- When the game is set 4P UPRIGHT A (No. 2 and No. 3 of DIP SW 2 OFF), only the coin mode 1 (No. 4 of DIP SW 2 OFF) can be used.
- When the game is set 4P UPRIGHT B (No. 2 of DIP SW 2 OFF and No. 3 of DIP SW 2 ON), 2P UPRIGHT (No. 2 of DIP SW 2 ON and No. 3 of DIP SW 3 OFF) or 2P TABLE TYPE (No. 2 and No. 3 of DIP SW 2 ON), either coin mode 1 (No. 4 of DIP SW 2 OFF) or coin mode 2 (No. 4 of DIP SW 2 ON) can be used.
- 1-COIN CONTINUE is the mode which starts the game with 2 coins but continues it with 1 coin alone. When this mode is set, no other coin modes can be set. For two players, 4 coins to start, 2 coins to continue.
- When the game is set 4P UPRIGHT A, each coin selector can be used independently.
- When the game is set 4P UPRIGHT B, a coin selector can be used as a mutual.

CN 3

1	GROUND
2	3P RIGHT
3	3P LEFT
4	3P DOWN
5	3P UP
6	3P START
7	3P COIN
8	3P REMOTE CONTROL BOMB
9	3P SETS BOMBS

CN 4


1	GROUND
2	4P RIGHT
3	4P LEFT
4	4P DOWN
5	4P UP
6	4P START
7	4P COIN
8	4P REMOTE CONTROL BOMB
9	4P SETS BOMBS



# ATOMIC PUNK PCB

NOTE: SET DIP SWITCHES FOR  
4 PLAYER UPRIGHT.  
USE EITHER UPRIGHT A  
OR UPRIGHT B  
TO SELECT EITHER  
COMMON OR INDIVIDUAL  
COIN ENTRIES

SET 2 PLAYER DIFFICULTY  
ON NORMAL  
SET 4 PLAYER DIFFICULTY  
ON EASY





ATOMIC PUNK

USE CONNECTOR CN3 & CN4  
FOR 3RD & 4TH PLAYER